

DL60-D70 quick connector guide*

***DL60-RF155 please see page 2**

Drawing 1: DL60-D70 with quick connect options




Table 1 - quick connector guide*

Dimmable (DALI / 1-10V)	1 (POWER IN)	2 (POWER OUT)
1xQCE	ENSTO NCC51 MALE	ENSTO NCC52 FEMALE
2xQCE	ENSTO NCC51 MALE	
1xQCA	WAGO MIDI 5P Blue MALE	WAGO MIDI 5P Blue FEMALE
2xQCA	WAGO MIDI 5P Blue MALE	
1xQCW	WIELAND GST18i5 Blue MALE	WIELAND GST18i5 Blue FEMALE
2xQCW	WIELAND GST18i5 Blue MALE	
Non-dimmable	1 (POWER IN)	2 (POWER OUT)
1xQCE HF	ENSTO NAC31 MALE	ENSTO NAC32 FEMALE
2xQCE HF	ENSTO NAC31 MALE	
1xQCA HF	WAGO MIDI 3P MALE	WAGO MIDI 3P FEMALE
2xQCA HF	WAGO MIDI 3P MALE	
1xQCW	WIELAND GST18i3 MALE	WIELAND GST18i3 FEMALE
2xQCW	WIELAND GST18i3 MALE	

***DL60-RF155 please see page 2**

DL60-RF155

Some versions of DL60-RF155 have internal sockets and plugs - drawing 2, table 2

Drawing 2: DL60-RF155 with internal sockets




Table 2 - versions using internal sockets **

Dimmable (DALI / 1-10V)	1 (POWER IN)	2 (POWER OUT)
1xQCE	ENSTO NCC51 MALE	
2xQCE	external plug (Table 1)	external socket (Table 1)
1xQCA	WAGO MIDI 5P Blue MALE	
2xQCA	WAGO MIDI 5P Blue MALE	WAGO MIDI 5P Blue FEMALE
Non-dimmable	1 (POWER IN)	2 (POWER OUT)
1xQCE HF	ENSTO NAC31 MALE	
2xQCE HF	ENSTO NAC31 MALE	ENSTO NAC32 FEMALE
1xQCA HF	WAGO MIDI 3P MALE	
2xQCA HF	WAGO MIDI 3P MALE	WAGO MIDI 3P FEMALE

**** All other versions including linect, emergency battery, etc. have body type described in drawing 1**