




Web-Site..... www.dnh.no

DSP-15(T)

GERMANY DNH GmbH

DNH Speakers Inc

Phone.....+ 1 484 494 5790 Fax....+ 1 484 494 5793 E-mail..dnh@dnhspeakers.com



DNH WW Ltd

Phone.....+ 44 1908 275 000

Fax.....+ 44 1908 275 100

E-mail.....dnh@dnh.co.uk

dBSPL	und pressure	SPL vs	Freq	(-20-51	7	
10							
05			m	My	M. 1		
00		/	1		M	N	
95		\sim				- 4	
90		-/-					
85		-/					
80		/				1	1
75		/					H
70							NI
65							700
60 Hz 50	100 200	500	1K	2K	5K	10K	2

Specifications				
Material / Color	ASA / RAL 7035			
Mounting	Bracket			
Termination	screw terminals			
Weight w/transformer	1,8 kg			
IP-rating	67			
Max. / min. amb. temp	90°C / -50°C			
Rated / max. power	15 W / 20 W			
SPL 1W/1m	106 dB			
SPL rated power	117 dB			
Effective freq. range	350 – 11000 Hz			
Dispersion (-6dB) 1kHz / 4kHz	200° / 47°			
Directivity factor, Q1kHz/4kHz	1,8 / 7,6			
Options	Impedances, colors, labels			

Installation, Operation and Maintenance Procedures

- Remove lid by four screws, lead cable through the cable gland and connect to terminal (White: Green 70V or White: Red 100V)
- Select required tapping on the transformer.
- Screw lid back into place by four screws with a torque of 1.3 1.8 Nm to assure the IP rating.
- To change the position of the loudspeaker, please adjust the standard U- bracket (by loosening / tightening the screws) as required.
- DSP-15(T) can be supplied with three different bracket systems, according to customer requirements.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- Do <u>not</u> open loudspeaker when energized.
- This loudspeaker is supplied with a two years warranty against defective workmanship.

((



DNH reserves the right to alter specifications without notice