# Accessories For easy installations




Putting safety first






#### **PACKING TOOL**


Compresses insert block to hold cable/pipes during partial installations.




I. Pull the cables through the frame



3. You can then pull more cables through the frame.



2. The packing tool keeps the cables and blocks into place.



4. The tool can be used to the last blocks and the endpacking.



### **QUICK RELEASE SPANNER**

For compression plate installation.




Tighten the bolt on the compression plate with the quick release spanner:

#### **BENEFITS**


- Easy re-entry into system
- Ideal for use together with quick release spanner
- Smoother disassembly of end packer without unnecessary damages




I. Remove the nuts and the hardware.



3. Thighten the bolt on the puller, the endpacking slides out.



2. Attache the endpacking puller to the bolts with the nuts.



4. Remove the endpacking.

## STG ENDPACKING PULLER

For re-entry into system.



## **CABLE SEPARATOR**

To aid installation of insert blocks by keeping away the interference of cables.



I.A cable seperator tool keeps away the interference of cables.



2. Position the cable seperator within the frame and tighten it up with the metal bar enclosed.



3. Insert blocks can now easily be installed.



### SPACER TOOL

Simplifies insertion of last row of blocks.



I. Choose the correct size of spacer tool, 20, 30 or size 40.



2. Insert the spacer tool between the two stay plates.



3. Turn it 90 degrees with help of a 13 mm spanner.



4. Turn back the tool 45 degrees and pull it out. Insert the last blocks.

#### RENIFFITS

- Helps you to choose the right insert block.
- For measuring of cables from 4 to 48 mm in diam.
- Easy to use and easy to carry.




#### I. Pull the cables through the frame



3. Put the tip through the incition and tightend the strip.



2. Put the measuring strip around the cable.



4. You can read out directly which MCT block to use.

## **BLOCK SELECTOR**For cable/pipe measurement.

#### MCT BRATTBERG SYSTEM

- Assist insertion of last block in each row
- Protect the copper sheets from
- Contribute to a functional EMC



#### **TWEEZERS**

Assist insertion of last block in each row.



I. Put some lubricant on both the tweezers blades and grab the block.



3. Press the block into the



2. Finsure the tweezers blades protrude at least 35 mm outside the block. Insert the tweezers blades in the frame.




4. Pull out the tweezers.


- Simplifies placement of marking where the cable sheath shall be cut
- Ensures that cables are positioned correctly in the blocks
- Contribute to a functional EMC




I. Pull the cables to final position. Put the EMC Marking Template in the frame with the yellow label facing you. Mark the cables.



2. Remove the cable sheath between the two lines in the



3. Push the exposed part of the cable screen so it is positioned over the metal sheet in the E-Insert Blocks. Ensure all the insert blocks having the yellow "E" markings facing you.



4. Complete the row of E-Blocks and insert the stay plate. Repeat on the rest of the cables.

#### **EMC MARKING TEMPLATE**

Ensures earth contact for all cables in the transit.



www.mctbrattberg.com

MCT Brattberg AB SE-371 92 Karlskrona Sweden

Phone: +46-455 37 52 00 +46-455 37 52 90 E-mail: info@mctbrattberg.se Website: www.mctbrattberg.se MCT Brattberg Ltd Commerce Street Carrs Industrial Estate Haslingden Lancashire BB4 5JT England

Tel: +44 - 170 624 4890 Fax: +44 - 170 624 4891 E-mail: info@mctbrattberg.co.uk MCT Brattberg Inc. P.O. Box 374 Spring Tx 77383 Phone: +1 (281) 355 8191 Fax: +1 (281) 355 8393

E-mail: info@brattberginc.com